

Tillykke med din Treasure Magnet

Du er nu klar til at gå på skattejagt i søer, vandløb og havet med din nye Treasure Magnet. Glæd dig til en masse sjov – og hvem ved hvad du kan finde af antikviteter, mønter og andre spændende ting som er gemt under vandets overflade?

Inden du går i gang, opfordrer vi dig dog til at læse denne korte instruktion, så du får mest ud af magneten og ikke kommer til skade.

Sådan gør du

1. Start med at skrue krog-øjet sammen med magneten. Det er vigtigt at du strammer krog-øjet ordentligt, så det ikke over tid frigør sig fra magneten og falder af.
Brug **Threadlocker 242** lim mellem krogøjet og magneten, hvis du ønsker permanent at fæstne.
2. Fastgøre herefter rebet* i krog-øjet.
3. Når rebet er fastgjort, så find et godt udkaststed. Dette kan f.eks. være ved en havn, bro, vandløb mm.
4. Inden du kaster magneten i vandet så sikre dig at der ikke er trafik på vandet eller at du kan ramme andre personer.






5. Kast magneten ud i en afstand 1-20 meter fra dit ståsted, og træk langsomt magneten ind. Trækker du for hurtigt risikerer du at de genstande du har fanget falder af.

Go fornøjelse 😊

*Det anbefales at bruge et reb på min. 20m og 6 mm. tykt.

Instruktion

En Treasure Magnet fra Treasurehunter.dk er en super-magnet. De fleste af vores magneter er designet med en trækstyrke på flere hundrede kilo. Den er sjov at bruge, men husk at gøre det med omtanke.

	Undgå at få fingere i klemme mellem magneten og andre metalobjekter.
	Brug handsker.
	Rengør og skyl magneten i alm. postevand efter brug for at undgå korrektion.
	Undgå kontakt med elektriske apparater. Magnetfeltet kan skade din telefon, pacemaker mm.
	Finder du eksplosive genstande som patroner, granater mm. rør da ikke genstandene og kontakt lokale myndigheder.

Congratulation with your new Treasure Magnet

You're now ready to go treasure hunting in lakes and streams. You can look forward to many hours of fun with your Treasure Magnet – and who knows what you will find of antiques, coins and other interesting objects from under the water surface.

Before you start we recommend that you read this instruction, so that you will get the most out of the magnet and avoid getting hurt.






How to use

1. Attach the eye-hook to the magnet. Tighten the eye-hook properly so it does not detach from the magnet when use.
Use **Threadlocker 242** glue between the magnet and eye-hook to permanently fasten.
2. Attach the rope to the eye-hook.
3. Once the rope is fastened, find a good fishing spot. This can be a harbor, bridge, stream etc.
4. Throw the magnet into the water in a distance of 1-20m. Slowly retract the magnet from the water. If you pull too fast you risk objects you have caught to fall off. Watch out for other people.

Enjoy 😊

Instruction

A Treasure Magnet from Treasurehunter.dk is a super-magnet. Most of our magnets are designed to carry several hundreds of pounds. It is fun, but use it wisely.

	Avoid getting your fingers pinched between the magnet and other metal objects.
	Use gloves.
	Clean and rinse the magnet in tap water after use to avoid corrosion.
	Avoid contact with electrical appliances. The magnetic field can damage your phone, pacemaker etc.
	If you find explosive objects like shells, grenades etc. then do not touch and contact local authorities.



treasurehunter.dk